ATV/UTV Contactor/Solenoid Wiring Instructions

Please Note: The last connection made will be the negative (BLACK wire) from the contactor to the battery. This will ensure there is no power to the winch system until you are ready for it. Double check all connections and make sure connections are clean and tight.

