

Template #1 (Top Half) Passenger Side Footwell

Use 5/16" Drill Bit

