



DENALI Plow Mount MA11120 Yamaha Kodiak/Bruin/Grizzly

Thank you for purchasing our DENALI plow mount. You now own a premium custom plow mount to allow you to use your plow with your ATV. Please note the following instructions and heed all warnings.

- Your ATV and/or plow system can cause death or injury, please use caution and common sense when operating your unit.
- Read your Plow Operator Manual, your Winch Operator Manual, and all warning labels before operating your ATV.
- Operate your ATV at a walking speed with the blade installed. Do not exceed 5 mph (8 km/h), even with the blade up.
- Do not operate the ATV on slopes greater than 10 degrees with the plow installed.
- Always lower the plow to the down position before leaving your ATV unattended.

SEVERE INJURY OR DEATH MAY RESULT IF YOU ARE NEGLIGENT.

PARTS LIST

Plow Mount & Tab

- (2) 1/4" x 1" hex head bolt
- (2) 1/4" flat washer
- (2) 1/4" nylock nut
- (4) 5/16" x 1 3/8" U-bolt (Fastenal #: 42018)
- (8) 5/16" washer
- (8) 5/16" nylock nut
- (1) 3/8" x 1" hex head bolt
- (1) 3/8" nylock nut

Plow Mount Assembly:

1. Attach the Tab to the Plow Mount with two 1/4" dia-1" long bolts, 1/4" washers, and 1/4" nylock nuts as shown in Figure 1. Align the tab edges to the plow edges before tightening. The heads of the bolt should be on the tab side while the washers and nuts on the underside of the plow mount.
2. Place the Plow Mount underneath the vehicle with the chamfered edges facing the front of the ATV. Place the Tab inside the rectangular opening of the skidplate. Jiggle the plow mount to be sure the tab is in the opening, there should be minimal movement. Be sure the plow mount is aligned properly and not rotated to one side.
3. Using a permanent marker (or similar), mark inside each of the eight open holes on the Plow Mount and onto the skidplate as shown in Figure 2. Remove the plow mount from the vehicle when finished. Do not remove the Tab.
4. With a drill and 3/8" bit, drill through the skidplate at each marked location with the exception of the two outside ones. Proceed slowly and drill only through the skidplate. Pay attention not to drill or damage any other component on the vehicle.
5. With diagonal shears (or similar) cut the sides of the skidplate removing the two outside marked locations.
6. Slide 5/6" dia-1 3/8" wide U-bolts over the vehicle frame and through each set of holes for a total of four. Due to vehicle design, the two center U-bolts can only be accessed on one side of the vehicle.
7. Place the Plow Mount back underneath the vehicle. Slide the ends of the U-bolts through the open holes on the mount. The Tab should fit back inside the rectangular opening in the skidplate.

8. Attach 5/16" washers and 5/16" nylock nuts to the end of each U-bolt. Tighten securely. The complete plow mount should look like Figure 3.

9. Attach the plow to the Plow Mount using the clip pins found in the plow blade kit.

