

Fits All Ranger Models with Extreme Front Bumper



FASTENING HARDWARE

(4) M12 hex head bolt

(4) M12 nylock nut II

INSTALLATION PREPARATION

1. Disconnect positive wire from the battery for safety

WINCH INSTALLATION

1. Mount your winch on the mounting plates provided. The roller fairlead mount comes in your winch kit. The winch should sit on top of your roller fairlead mount. Then the fairlead mount sits on top of the long, rectangular mount and the full assembly should be attached together.
2. Slide the terminal boots onto the blue and yellow wires before attaching them to the motor on your winch. Install blue and yellow wires to your winch motor.
3. Mount your winch assembly to the top of your Extreme Brushguard using the (4) M12 bolts and (4) nuts provided.
4. Route the cable through the roller fairlead. Attach roller fairlead with hardware provided in winch kit. Install hook and hand saver at this time.

CONTACTOR INSTALLATION

1. Attach the contactor to the contactor mount included with the winch kit.
2. Locate the mounting holes under the hood and mount the contactor.
3. Refer to wiring diagrams in winch instruction booklet to complete wiring install.
4. Use zip ties to secure all wiring.