



motoalliance



HIGHLANDS

— C A R G O —

Polaris RZR XP 1000 Cargo Box
JC11101_XPII

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS Cargo Box
2	4	JC_Anchor_1

INSTALLATION INSTRUCTIONS

1. Open your new HIGHLANDS Cargo Box and locate the four drilled holes on the bottom of the box.
2. Unthread the four included anchors (JC_Anchor_1) and put the threaded quick release and washer inside the box through the drilled holes.
3. Loosely re-thread the rubber section to the quick release on the bottom side of the cargo box.
4. Place the cargo box into the bed of your machine. It may take a few tries to carefully lower the box so the anchors enter into the lock and ride holes of your machine.
5. Once the box is fully seated in the bed, open the box, and tighten the quick release anchors. Once adequately tightened with the lever up, press the lever down to lock the anchors in.

