



motoalliance



HIGHLANDS

— C A R G O —

**Can-Am Commander Bed Cover
JC11142_Commander**

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS JC11142_Commander Bed Cover
2	4	JC_Anchor_5

INSTALLATION INSTRUCTIONS

1. Open your new HIGHLANDS bed cover and locate the four drilled holes on the base section of the cover.
2. Unthread the four included anchors and put the rubber section on the bottom of the base and put the bolt with the washer through the holes on the inside of the base.
3. Loosely re-thread the bolts so that the anchor assembly is secure.
4. Place the bed cover on your machine. It may take a few tries to carefully lower the cover so the anchors go into the factory locations on your machine.
5. Once the cover is fully seated on the bed, open the lid and tighten the bolts while pressing down on the bed cover to ensure a tight seal.

