



Bombardier Outlander
Fits all 2003-2005 models – MA11940

330 Outlander 2x4 - 2005
330 Outlander 4x4 - 2004
400 Outlander Max - 2005
400 Outlander 4x4 - 2003-2005

***All directions referring to left and right are when rider is sitting on the ATV. ***
*** Two bolt winch (Viper/Superwinch) motors should be on the left side ***

-2-BOLT PATTERN WINCHES

For Viper, Cycle Country, Superwinch and other 2-bolt winches: The winch will need to be fastened with the two 5/16" x 1" bolts to the TOP mount plate before attaching the bottom mount plate.

-4-BOLT PATTERN WINCHES

For Warn and Ramsey winches: Bolt to the BOTTOM mount plate using the four hole pattern located around the winch cable access point. Use the two 5/16" x 3/4" flathead bolts & the two 5/16" x 3/4" bolts provided with the winch. Tighten.

INSTALLATION INSTRUCTIONS

- 1) Remove the front bumper guard.
- 2) Place the bottom winch mount plate on the two brushguard tubes. Use the 2 U bolts to attach the front side of the plate to the tubes. Do NOT tighten.
- 3) Place the top winch mount plate with winch attached on top of the bottom mount plate. Use the two 5/16" bolts to attach both plates to the brushguard
- 4) Secure all hardware

HARDWARE FOR WINCH MOUNT KIT

QTY	DESCRIPTION
1	Top Mount Plate
1	Bottom Mount Plate
4	3/8" Nylock Nuts
2	3/8" U-Bolt 1-1/2" x 2-1/2"
4	5/16" Nylock Nuts
4	5/16" x 1" Bolt
2	5/16" x 3/4" Flat Head Bolt