



DENALI Plow Mount MA11707 Polaris Ranger

Thank you for purchasing our DENALI plow mount. You now own a premium custom plow mount to allow you to use your plow with your SxS. Please note the following instructions and heed all warnings.

- Your UTV/SxS and/or plow system can cause death or injury, please use caution and common sense when operating your unit.
- Read your Plow Operator Manual, your Winch Operator Manual, and all warning labels before operating your UTV/SxS.
- Operate your UTV/SxS at a walking speed with the blade installed. Do not exceed 5 mph (8 km/h), even with the blade up.
- Do not operate the UTV/SxS on slopes greater than 10 degrees with the plow installed.
- Always lower the plow to the down position before leaving your UTV/SxS unattended.

SEVERE INJURY OR DEATH MAY RESULT IF YOU ARE NEGLIGENT.

**Polaris Ranger
MA11707**



motoalliance

22000 Industrial Blvd, Ste 250

Rogers, MN 55374

866.527.7637

Please verify that all hardware and parts are included in your package.

Kit Contents:

Item Number	Quantity	Part Number
1	1	MA11707 Plow Mount
2	4	3/8 x 1 1/4" Bolts
3	4	3/8" nylock nuts
4	8	3/8" Flat Washers1
5	1	Mount Strap

Polaris Ranger Installation Instructions

1. Install front plow mount to the machine by first removing the three bolts under the machine, shown in illustration. Attach plow mount reusing the bolts you just removed, align for best fit and just snug bolts at this time.
2. The top of the mount will be held in place with four $\frac{3}{8}$ x $1\frac{1}{4}$ " bolts. Install the four $\frac{3}{8}$ x $1\frac{1}{4}$ " bolts and flat washers from the front through the mount and through the machine and use the formed strap on the inside. Use four flat washers and Nylock nuts to secure. Tighten all bolts.
3. **Note:** After use recheck bolt tension Use two quick release pins to attach plow to plow mount.

