



Polaris RZR 1000 XP Plow Mount MA11702

INSTALLATION INSTRUCTIONS

Thank you for purchasing a DENALI Plow Mount.

You now own a premium, custom plow mount to allow you to use your plow with your UTV/SxS. **Please note the following instructions and heed all warnings.**



- Your UTV/SxS and plow system can cause death or injury. Please use caution and common sense when operating your unit.
- Read your Plow Operator Manual, your Winch Operator Manual, and all warning labels before operating your UTV/SxS.
- Operate your UTV/SxS at a walking speed with the blade installed. Do not exceed 5mph (8km/h) even with the blade up.
- Do not operate the UTV/SxS on slopes greater than 10 degrees with the plow installed.
- Always lower the plow to the down position before leaving your UTV/SxS unattended.


SEVERE INJURY OR DEATH MAY RESULT IF YOU ARE NEGLIGENT.

PARTS LIST



Please verify that all hardware and parts are included in your package.

Part#	Qty	Item Description
1	1	MA11702-1 Main Bracket
2	1	MA11702-3 Side Bracket
3	1	MA11702-2 Back Bracket
4	4	3/8-16x1.25" Hex Bolt
5	8	3/8" Washer
6	4	3/8-16" Nylock Nut
7	2	3/8-16x1.75" Serrated Flange Bolt
8	1	MA11702-4 Side Bracket



1. Remove the two bolts off the bumper.

2. Place mount up and insert those two bolts.



FIGURE 1

3. Place side brackets and secure with 3/8" hardware.




FIGURE 2

4. Lineup MA11702-1 with the holes in the skid plate and secure with the flange bolts.



FIGURE 3