



22000 Industrial Blvd, Rogers, MN 55374
866-527-7637
www.motoalliance.com

DENALI Plow Mount MA11747 CanAm Maverick

Thank you for purchasing a DENALI plow mount. You now own a premium, custom plow mount to allow you to use your plow with your UTV/SxS. Please note the following instructions and heed all warnings.

- Your UTV/SxS and plow system can cause death or injury. Please use caution and common sense when operating your unit.
- Read your Plow Operator Manual, your Winch Operator Manual, and all warning labels before operating your UTV/SxS.
- Operate your UTV/SxS at a walking speed with the blade installed. Do not exceed 5 mph (8 km/h) even with the blade up.
- Do not operate the UTV/SxS on slopes greater than 10 degrees with the plow installed.
- Always lower the plow to the down position before leaving your UTV/SxS unattended.

SEVERE INJURY OR DEATH MAY RESULT IF YOU ARE NEGLIGENT.


Please verify that all hardware and parts are included in your package.

**DENALI CanAm Maverick
MA11747**

Kit Content:

Please verify that all hardware and parts are included in your package.

Item Number	Description	Quantity
1	MA11747 Plow Mount	1
2	Rear Support Bracket	1
3	Side Support Brackets	2
4	5/16" x 2 1/2" Serrated Flange Bolt	4
5	5/16" x 1 1/4" Serrated Flange Bolt	4
6	5/16" U-bolt (42024)	1
7	5/16" Serrated Flange Nuts	10




Installation Instructions

1. Remove the two front triangle shaped plastic guards as shown in the picture below



2. Remove the next four retainer bolts that hold the plastic underbody as shown in the picture below.



a.

Remove the two 1/4" U-Nuts that are attached to the frame just behind the differential. The U-Nuts are most easily removed using a small flat head screw driver to lift up the retainer clip. These will no longer be needed. With the U-nuts removed, you can replace the rear most M10 bolts that were taken off in Step 2.




3. From the top side of the underbody, behind the differential you will find four holes. Place the Rear Support Bracket on top of the holes and drop (2) of the 5/16" x 2 1/2" Hex Head bolts and 5/16" flat washers down from the top as shown below. **Note: only use the front most bolt holes at this time.**



4. Lift the plow mount up to the bottom of the Maverick such that the two bolts stated earlier align with the bolt holes in the mount. Use (2) of the 5/16" Serrated Flange Nuts to secure the rear bolts and hold the mount up to the frame. **Note: the plastic underbody will be sandwiched between the frame & the mount**
5. Once the mount is held in place you will need a 5/16" drill bit to clearance (4) holes in the plastic underbody. You will use the mount as a guide to drill the holes. Clearance out the rear most holes and the front two holes that are aligned in the center of the mount.
6. After the holes are drilled, unscrew the (2) 5/16" nuts and pull the mount down.
7. Locate the 5/16" U-bolt in your hardware kit. Slide the U-bolt sideways until it is positioned over the front cross support tubing. Allow the two ends of the U-bolt to drop around the tubing and raise the plastic underbody up to the legs as shown below and insert the two ends of U-bolt into the newly drilled holes in the plastic underbody.



- a. 
8. Raise up the plow mount again to the rear 5/16" bolts and the newly inserted U-bolt. Secure each with the 5/16" Serrated Flange Nuts.
9. Drop the remaining 5/16" x 2 1/2" Hex Head Bolts and washers through the newly drilled holes in the rear of the mount. Secure with the Flange Nuts.
10. Position the Side Support Brackets on either side of the mount and secure them with the remaining 5/16" Hex Head Bolts, washers and flange nuts. Verify all the bolts are secure.